

HOOC CONNECT T

Manual

GB STEP 1

Network integration

Connect network cable and power supply.
Wait for 60 seconds!

GB STEP 2

Ready Fail

BLINK CODE

WHITE FLASHING ●●●●●○

WHITE PERMANENT ●●●●●○

WHITE PERMANENT ●●●●●○

WHITE PERMANENT ●●●●●○

Go to STEP 3

LED-Power

LED-Uplink

LED-Status

www.hooc.ch/connect/fail

GB STEP 3

[www.hooc.ch /connect](http://www.hooc.ch/connect)

Login

Add Site

Link HOOC Connect

Serialnumber

HOOC Connect T Technical Data

Supply	Supply voltage	5 VDC
	Power consumption*	max. 1.65 W
	Current consumption*	330 mA
Enclosure	IP 20	
Safety class	II	
Temperature	Operation	0 °C to +45 °C
	Storage	-25 °C to +55 °C
Design	Dimensions	30 x 150 x 100 mm (HxWxD)
Network	The IP address is received from the DHCP server.	
	Permanent static address for service.	IP: 172.17.17.17
		Subnet: 255.255.255.0
Copyright ©	HOOC AG, Torweg 8, CH-3930 Visp	* Exclusive external devices

Interfaces and controls



Power LED

Description

	Start phase 1. device is not yet ready for operation
	Start phase 2. device is not yet ready for operation
	Normal operation

Uplink LED

Description

Possible cause of error

	Start phase 1. device is not yet ready for operation	
	Start phase 2. device is not yet ready for operation	
	Configuration mode is active	
	Normal operation	
	No connection to the local Network	<ul style="list-style-type: none"> The network cable is not plugged in or there is no device (e.g. switch) at the other end of the network cable. Network cable defective
	Can't obtain an IP address	<ul style="list-style-type: none"> There is no DHCP server in the network segment of the HOOC Connect.
	Default gateway is unreachable	<ul style="list-style-type: none"> There is no default gateway (router) in the network segment of the HOOC Connect. Default gateway blocks ICMP requests.
	DNS Server is unreachable	<ul style="list-style-type: none"> The DNS server used is not configured correctly. The DNS server (local or provider's) cannot be reached. If the provider's DNS server is used, the firewall may block access (e.g. 8.8.8.8 - google).
	No connection to HOOC Cloud	<ul style="list-style-type: none"> There is no internet connection. Port 443 (outgoing) may be blocked by the firewall. You may be using a web proxy. The connection to the HOOC Cloud does not work behind a Webproxy.

Status LED

Description

Possible cause of error

	Start phase 1. device is not yet ready for operation	
	Start phase 2. device is not yet ready for operation	
	Normal operation	
	Processor temperature greater than 80 °C	<ul style="list-style-type: none"> Operating ambient temperature too high
	No connection to time server	<ul style="list-style-type: none"> There is no internet connection. Port 443 (outgoing) may be blocked by the firewall. You may be using a web proxy. The connection to the HOOC Cloud does not work behind a Webproxy.
	No connection to log server	<ul style="list-style-type: none"> There is no internet connection. Port 10514 (outgoing) may be blocked by the firewall. This error can be ignored because the log server is not necessarily used.

Configuration


The IP configuration of the HOOC Gateway can be changed by creating and downloading a corresponding configuration file for the HOOC Gateway in the HOOC Management Portal.

To activate the configuration mode of the HOOC Gateway, the operating button of the device must be pressed briefly (less than one second) using a blunt object (e.g. paper clip).

The device is in configuration mode when the Uplink LED is orange. The configuration mode is active for 5 minutes after activation. The installation rod is now displayed on the device's website.

Connect your computer to the network in which the HOOC Gateway is located and follow the steps below:

1. Static configuration of the network adapter of your computer with the IP address 172.17.17.16 and the subnet mask 255.255.255.0
 2. Open the web page 172.17.17.17
 3. Now select the downloaded IP configuration and load it onto the device
 4. Wait until the configuration is completed and confirm it with the "Reboot system" button
-



Info

If no restart is made, it can lead to a malfunction.

Tip

If there have been problems with your configuration, it is possible to restore the HOOC Gateway to its factory settings. Press the control button for at least 15 seconds when the gateway is started. The start of this process is indicated by the two LEDs Uplink and Status being switched off and the power LED lighting blue.

